

LG ACCESSIBLE LIVING SOLUTIONS INC.



1.800.930.0904

With LG Accessible Living Solutions, you get more than compliance — you get quality, innovation, and peace of mind.

PARTNER WITH US

When you choose LG Accessible Living Solutions, you're choosing more than ADA compliance — you're choosing superior design, durability, and long-term peace of mind. Let's make accessibility a standard of excellence in every project.



Email:
info@lgshowers.com



Phone:
[1.800.930.0904](tel:1.800.930.0904)



For More Information:
www.lgshowers.com

1-Piece Shower

with solid core, reinforced bottom

- 1 Check shower pocket area for level and for correct dimensions. Make sure drain hole in floor is in the correct position.




Figure 1

- 2 **DRY-FIT THE SHOWER:** Set shower unit in the pocket. You **MUST** use a level to ensure unit is level. Shim if necessary.




Figure 2

- 3 Remove shower unit from the framing pocket. Have a plumber install drain fitting in shower bottom (see Steps 7–10). Plumber should also prepare drain pipe to receive the drain.

! To avoid deforming the shower bottom, once drain fitting is installed **DO NOT** store the unit resting on the drain.

- 4 Sweep the floor and remove all debris from pocket area, then position shower in pocket.
- 5 Make sure floor drains properly by pouring water on it or ensuring there is slope towards the drain with a level. If in doubt, remove shower and review the previous steps.




Figure 3

- 6 Screw flanges to framing at 12" maximum on-center vertically and horizontally at each stud.




Figure 4

Cross-section of drain (installed)




Figure 5

- 7 Remove inside compression nut and compression gasket.
- 8 Apply silicone or plumber's putty around shower drain hole on the inside of shower only.
- 9 Install drain body in shower drain hole.
- 10 Install rubber gasket, fiber gasket and locking nut; tighten locking nut.
- 11 Install shower unit over drain pipe (or install pipe later.)




Figure 6

- 12 Slide inside compression gasket into drain body and slip over pipe. **Make sure beveled end of inside compression gasket is facing up and is flush with pipe surface.**
- 13 Tighten inside compression nut into drain body using the tool provided.